# SGI Pastry

















## The Art of Spraying

Spray Guns: User Guide and Cleaning




### 🚏 Principle Diagram



3 key optimal settings: the spray pattern, the product flow, and the air pressure.

→ A pressure between 0.2 and 1.5 bar is recommended depending on the product to be applied.







### Manual Cleaning of the Spray Gun



For optimal cleaning, it is recommended to use the accessories below.

Large Cleaning Brush ( pack of 5 pieces) Réf. 1158840



**Dual-Sided Cleaning Brush** (pack of 10 pieces) Réf. 1009209



Spray Gun Cleaning Video

#### Manual Cleaning of the Spray Gun.

When performing manual cleaning, ensure that the brushes or brushes used are free of metal wires that could damage the spray gun. No cleaning liquid should enter the air channels of the spray gun.

#### Disassembly of the Nozzle Kit.



Prepare your included cleaning tools, along with a container and your spray gun.



1 - When cleaning the spray gun, first remove the paint needle.



2 - Unscrew the air cap.



3 - Then, disassemble the air cap.



4 - Finally, the fluid nozzle should be unscrewed using the wrench integrated into the universal tool.



5 - Then, disassemble the nozzle.





#### Cleaning of the Spray Gun Body and Nozzle Kit.



1 - Prepare warm water in a contai- 2 - Place the spray gun in the ner with dishwashing liquid.



container.



3 - Let the spray gun soak for 1



4 - Disassemble the needle and the air cap (see steps in "Nozzle Kit Disassembly").







5 - Clean the air cap on both sides using the cleaning brushes.







6 - Rinse the air cap on both sides with clean water.

7 - Clean the needle with the brush.



8 - Rinse the needle with clean water.



9 - Disassemble the nozzle (see steps in "Nozzle Kit Disassembly").



10 - Clean the nozzle on both sides using the cleaning brushes.











11 - Clean the nozzle on both sides using the cleaning brushes.

12 - Rinse the nozzle on both sides









13 - Clean the spray gun body and the paint channel using the cleaning 14 - Rinse the spray gun body and the paint channel with clean water. brushes.









14 - Rinse the spray gun body and the paint channel with clean water.

15 - Dry using an air blower.









16 - Dry the needle.

17 - Dry the nozzle.


When cleaning the components of the nozzle kit, ensure that the metal parts of the brushes do not damage the kit. Prefer using brushes and cleaning tools specifically designed by SATA, as well as SATA nozzle cleaning needles, to ensure optimal maintenance and thorough cleaning of the nozzle kit.





### Spare Parts SATAJet 1000 B RP Pastry Edition

P// /P/ 1: 11	
Réf. / Désignation	
1826 Anti-drip system (4x)	
3988 Paint strainer, 300 μ (10x)	
6395 CCS clips green, blue, red, black (one of each)	
15438 Paint needle seal	
16162 Paint needle seal	
27243 0.6L QCC reusable plastic cup, cpl.	
49395 Threaded lid with anti-drip ring and a drip system	nti-
89771 Pin for round/flat spray adjustment	
91959 Air piston rod	
130492 Trigger kit	
133926 Spacer kit	
133934 Seal (3x) for pin	
133942 Seal fastening, cpl.	
133959 Pressure spring (3x) for paint needle and air piston	
133967 Fixing screw (3x) for air micrometer	
133983 1/4" male-threaded air connection piece	
133991 Air piston head (3x)	
139188 Product flow adjustment with locknut	
139964 Air micrometer	
140574 Adjustment knob with screw	
140582 Sealing element (5x) for paint nozzle	
143230 Air distribution ring (3x)	
0.75L QCC aluminum cup with	
71555 Plastic lid (3x) for 0.75L and 1.0L rigic aluminum cup	i








## Spare Parts SATAMinijet 4400 B HVLP / RP

Réf. / Désignation	
3988	
Paint strainer, 300 μ (10	IX)
16295 25ml glass cup with plug	ı-in
lid	5 111
53033	_
25ml glass cup with plug	g-in
lid (5x) 58164	
25ml glass cup with blin	d lid
(5x)	
64022 Blactic lid (2v)	
Plastic lid (3x) 13398	
1/4" male-threaded air	connection piece
197418	
CCS clips green, blue, re	ed, black (one
of each) 197467	
197407 Air distribution ring (3x)	
197541	
0.125L reusable plastic	QCC cup,
cpl.	
197558 Anti-drip system (4x)	
198408	
Air piston rod	
198473 Trigger kit	
Trigger kit 198523	
Air micrometer	
198549	
Pin for round/flat spray	adjustment
198911 0.151. rousable aluminur	יי טכב כוויי
0.15L reusable aluminur cpl.	ii que cup,
199075	
Threaded lid with anti-c	Irip ring and
system 199406	
199406 Product flow adjustmen	t with
locknut	
199414	sistan rad
Paint needle seal & air ¡ seal	מסוו ווסזפוע
199430	
Fixing screw (3x) for air	micrometer
199448	
Air piston head (3x) 199455	
199455 Sealing element (5x) for	paint
nozzle	·
199463	<u></u>
Spacer kit	
199471 Seal (3x) for pin	
201467	
Pressure spring (3x) for	paint needle &
air piston	
200162 Adjustment knob with so	rew (2 of each
piece)	LIEW (Z UI EACII
200220	
Plug-in cup adapter with	n QCC
200238	
25ml glass cup with plug lid (5x) & QCC plug-in	g-ın
adapter (1x)	
200907	
Sealing ring (5x)	
16162	

16162 Swivel connector






## Spare Parts SATAJet 20 B

Réf. / Désignation	
860	
ATA air micrometer 0-845, G	j
9878	_
ATA mini filter G 1/4"	
	_
5669 5ml reusable plastic cup,	
pl.	
5909	_
Threaded lid	
6295	_
5ml glass cup with plug-	
n lid	
2987	_
ATA transparent PVC air	
ose, 3m long, with G	
/4" female thread,	
luick-connect mini	
oupling, and nipple	_
5188	
Pressure spring for air	
viston	_
5196	
Air piston head	_
4834 vir. pictop rod	
Air piston rod	
0807	
eal kit for air piston od	
i3033	-
5ml glass cup with plug-	
n lid (5x)	
i8164	_
5ml glass cup with blind	
id (5x)	
2042	
Gun grip	
2083	
ir tube	
2729	
Closure screw	
2802	
ressure screw G 1/8" male	
2869	
Product flow adjustment scre	w
4758	
)-ring seal	
6928	
air connection adapter G1/8"	,
nale - G1/4" male	
8817	
ressure spring for paint	
ieedle	
9344	
aint needle seal	
9913	
rigger kit	
25955	
Plug-in cup adapter with	
QCC	
25963	
5ml glass cup with plug-in	
id (5x) & QCC plug-in	

adapter (1x), funnel strainer

(150µm) (2x)





## SGI Pastry



Your catalog always with you!



Vanessa **HENRION** SGI Pastry Manager **Email:** contact@sgi-pastry.com **Mobile:** + 33 (0)6 30 03 23 27 **Website:** www.sgi-pastry.com

After-Sales Service: sav@sgi-pastry.com

"We are at your disposal to advise you on the most suitable equipment for your daily use. Optimal results are achieved through a combination of high-quality equipment, a sufficiently powerful air supply, and your expertise!"



**SGI - SPRAY GUN IMPORT** 

11 rue des Prés de Lyon 10600 La Chapelle-Saint-Luc



@sgi\_pastry
@vanessa\_sgi\_sata



CGV SGI "Métiers du Dessert".

## -SGIPastry-



**Testimonial** Jean-Christophe Jeanson

Executive chef at Maison Caffet Meilleur Ouvrier de France

www.sgi-pastry.com